



Figure 2: Addition > Comfort accessories > Window lifters > without passenger door module > 2006-01-01 - ... (Zoomed image section)

Components

Should components occur several times, the number is indicated in brackets after the component designation.

#1	Fuse 7.5 A
#2	Central cabin electrics
#3	Diode
30	High equipment level
30A	Fuse 30 A (4)
31	High equipment level
60A	Maxi fuse 60 A (2)
A10	ENGINE COMPARTMENT ELECTRONIC MODULE
A10b	Central electrics Bootspace
A31	DOOR ECU FL
C-LS	High equipment level (3)
C21	High equipment level (2)
C33	High equipment level (3)
C34	High equipment level (2)
C43	High equipment level (2)
C44	High equipment level (2)
G21	High equipment level (2)
G22	High equipment level (2)
LS	High equipment level (7)
M35	POWER WINDOW DRIVE Front FL
M36	POWER WINDOW DRIVE Front Passenger side
M45	POWER WINDOW DRIVE RL
M46	POWER WINDOW DRIVE RR
S21b	Power window deactivation switch
S21c	Power window selector switch
S21w	Window lifter switch FL
S22rf	Power window switch Passenger side
S22w	Switch for power window in passenger door
S31lr	Power window switch RL
S32rr	Power window switch RR
bg	High equipment level
bl	High equipment level
br	High equipment level
ge	High equipment level
gn	High equipment level
gr	High equipment level
hbl	High equipment level
hr	High equipment level